

DEVICE ACTUATION UNIT





Figure 4



TRAINING MODE MESSAGE TRANSMITTED FROM HAND-HELD UNIT TO DEVICE ACTUATION UNIT

HAND-HELD ID	MESSAGE LENGTH (# OF BYTES)	DEVICE ACTUATION UNIT ID	TRAINING MODE CODE	CHECKSUM	
11111111	00000101	00000001	11110000	11110001	
<u>Figure 7A</u>				170	

ACKNOWLEDGEMENT MESSAGE TRANMITTED FROM DEVICE ACTUATION UNIT TO HAND-HELD UNIT AFTER DEVICE ACTUATION UNIT RECEIVES TRAINING MODE MESSAGE

HAND-HELD ID	MESSAGE LENGTH	DEVICE ACTUATION UNIT ID	DEVICE ACTUATION UNIT ID	CHECKSUM
11111111	00000101	00101 00000001 00000001		00000010
	172			

DEVICE SELECTION MESSAGE TRANSMITTED FROM HAND-HELD UNIT TO FOOT-PEDAL CONTROL SYSTEM TO SELECT DEVICE


ACKNOWLEDGEMENT MESSAGE TRANSMITTED FROM FOOT PEDAL CONTROL SYSTEM TO HAND-HELD UNIT AFTER FOOT-PEDAL CONTROL SYSTEM RECEIVES DEVICE SELECTION MESSAGE


HAND-HELD ID	MESSAGE LENGTH	DEVICE ACTUATION UNIT ID	DEVICE ACTUATION UNIT ID	CHECKSUM
11111111	00000100	0000001	00000001	00000010
Figure 8B				176


DEVICE ACTUATION MESSAGE TRANSMITTED FROM FOOT PEDAL CONTROL SYSTEM TO DEVICE ACTUATION UNIT FOR "ON-OFF" CONTROL OF A DEVICE

DEVICE ACTUATION MESSAGE TRANSMITTED FROM FOOT PEDAL CONTROL SYSTEM TO DEVICE ACTUATION UNIT FOR VARIABLE CONTROL OF A DEVICE

		DEVICE ACTUATION	VARIABLE	COMMAND	
HAND-HELD ID	MESSAGE LENGTH	UNIT ID	ACTUATION CODE	CODE	CHECKSUM
11111111	00000110	00000001	11110000	00000001	11110010
Figure 10					5
<u> 1 18 110 </u>				180	













Figure 12B











DEVICE ACTUATION UNIT








Figure 18